


INTERMATIC TIME-ALL® HEAVY DUTY TIMER

PROGRAM REPEATS EVERY 24 HOURS
TO SET TIMER: (SEE ILLUSTRATION)



(C) TRIPPERS
(B) TIME-OF-DAY MARKER
(A) MANUAL KNOB

1. Insert **ON (RED)** and **OFF (BLACK)** trippers(C) into dial at desired **ON** and **OFF** times.
2. Turn dial **CLOCKWISE**  one or more complete revolutions until the correct time-of-day is adjacent to the time-of-day marker (B).
3. Turn lamp or appliance **ON** and plug into timer.
4. Plug timer into electrical outlet.

FOR EARLY ON OR OFF OPERATION,
Turn manual knob (A) counter clockwise  to desired **ON** or **OFF** position. Timer will follow next scheduled automatic operation.

IN CASE OF POWER FAILURE, RESET TIMER, (SEE STEP 2)

⚠ WARNING Risk of Fire

WATTAGE OF LAMPS OR APPLIANCES BEING CONTROLLED SHOULD NOT EXCEED CAPACITY OF TIMER.

MODEL: HB112

CONTACT: 2 HP (8 FLA, 48 LRA), (8A. AIR CONDITIONER)
15 A RESISTIVE, 8 A INDUCTIVE

768 VA PILOT DUTY, 240 V AC, 60 Hz.

CLOCK MOTOR: 240 VOLT 60 Hz.

MADE IN MEXICO

SA LR3730
C US

INTERMATIC INCORPORATED
SPRING GROVE, ILLINOIS 60081-9698